

# How to Enable Power Saving Functionality in Wi-Fi driver

If you would like to enable/disable Power Saving Function in Wi-Fi driver, you can follow as below setting before compiling Wi-Fi driver.

Enable Power Saving Function:

Set CONFIG\_POWER\_SAVING to y in Makefile  
e.g. **CONFIG\_POWER\_SAVING = y**

Disable Function:

Set CONFIG\_POWER\_SAVING = n in Makefile  
e.g. **CONFIG\_POWER\_SAVING = n**